Microplasticity and High Ductility During Microtensile Testing of Free-Standing Aluminum Films

R. R. Keller, D. T. Read, Y.-W. Cheng, and J. D. McColskey National Institute of Standards and Technology, Materials Reliability Division Boulder, Colorado





Thin Film Ductility

- Affected by: fine grain size, film dimensions
 - scaling effects are important since microplasticity exhibits characteristic dimensions (cells, PSBs, etc.)
- Measured by: microtensile tests on free-standing films or films on elastic substrates, bulge tests
 - other test methods do not provide information about elongation






Specimens

- Pure AI, e-beam deposited onto bare Si
- Si etched away using XeF₂, leaving free-standing Al
- Gauge section:

10 μm x 180 μm x 1 μm




100 μm






Microtensile Test in SEM







What We See



20 μm

SEM image sequence taken over 3 minutes.

$$\dot{x} = 0.3 \mu m / s$$


ε ~ **30**%





Mechanical Properties

6 Tests:



Ductility

- Mean: 22.5%
- Range: 13 32
- Std. Dev.: 5.0 0.2% Offset σ_{vs}
- Mean: 93.8 MPa
- Range: 87 105
- Std. Dev.: 10.1

<u>UTS</u>

- Mean: 151.0 MPa
- Range: 124 176
- Std. Dev.: 19.8






Microstructure by TEM

Can observe films without thinning

- 0.3 μm grain size
- Few dislocations have accumulated, even after fracture
- No information on texture or deposition stresses



Al film strained to ~ 24%; Image from uniform deformation region.





High Ductility and Uniform Deformation

High strain rate sensitivity exponent, m, ~ 0.20:

$$\sigma = C\dot{\varepsilon}^m$$

Other thin film tests: compare > 40% for m = 0.26 and ~ 3% for m = 0.1 $dA/dt = (1/C')F^{(1/m)}(1/A^{\frac{1-m}{m}})$

Area reduction occurs more slowly for higher m.

High strain hardening coefficient, n, ~ 0.12:

$$\sigma = K\varepsilon^n$$

Uniform strain until $\varepsilon_t = n$.

Necked area strengthens more, adds to strain rate effect, "spreading" the strain.


These properties promote more uniform deformation.






What About Dislocations?

Grain shapes by TEM: 350 - 400 grains/sample





As-Deposited

Deformed

Plastic compatibility must be maintained, otherwise grains 'overlap' or show voiding at boundaries.

Can use geometrically-necessary dislocations to accommodate strain.





How Many Dislocations?

$$|\overline{\varepsilon}| = \frac{\delta l}{l} = Nb/d$$

total strain in one average grain, to maintain compatibility

$$\rho_{G} = N / area_{grain} = \frac{\overline{\varepsilon}d}{b \cdot area_{grain}}$$

N = number of dislocations to cause displacement

$$\bar{\varepsilon} = 0.24$$

 $b = \text{Burgers Vector} = 2.86 \cdot 10^{-8} \, \text{cm}$

 $d = \text{average grain diameter} = 0.3 \cdot 10^{-4} \, \text{cm}$

$$area_{grain} = \pi d^2 / 4$$

$$\Rightarrow \rho_G = 3.56 \cdot 10^{11} / cm^2 (= 3560 / \mu m^2)$$

 $\rho_{\rm G}$ -volume_{grain} = 160 μ m = total line length to give ϵ = 24%

→ ~ 500 / test

For a 500 s test, can we get 1 dislocation/s ($v \sim 0.3 \mu m/s$)?





Summary

- Microtensile tests on free-standing AI within SEM
- Ductilities averaging > 20%
- Pronounced strain rate effect: necking delayed
- Simple concepts of geometrically-necessary dislocations may be able to account for high elongation



